



## Foam Tape Installation Instructions

1. Clean and dry the surface of existing or new grip area.
2. Measure the appropriate length of Rod Armor for grip area.
3. Carefully apply the rubber tape to the grip area starting from the smaller diameter to the larger. Use care to ensure there are no gaps in the application. Apply tape evenly and smoothly for best results. Do not stretch.
4. Stop applying the tape 1" to 2" from the end of the grip area. This will make the installation process easier.
5. Trim top and bottom square to grip.
6. Remove the backing from the tape.
7. Hold the rod vertical.
8. Squeeze the Rod Armor on the fold to open. This allows for the space required for insertion.
9. Once the Rod Armor is open, insert the grip area using a slow twisting motion in the direction of the tape wrap.
10. Stop when the Rod Armor reaches the desired location.
11. Use a heat gun to shrink the Rod Armor around the grip area.
12. **DO NOT USE A FLAME FOR THIS PROCESS!!**
13. Trim the Rod Armor if necessary.

Visit our website for step by step visual instructions.

**P.O. Box 1988, Glendora California 91740**  
**office (626) 963-1142 fax (626) 963-8672**  
**[tim@swiftymfg.com](mailto:tim@swiftymfg.com) [www.swiftymfg.com](http://www.swiftymfg.com)**

*Swiftly Manufacturing is dedicated to helping anglers nurture the environment by providing high quality, environmentally safe fishing products.*