



Nu-Skin Reel Armor Installation Instructions

1. Prepare the reel by wiping all the surfaces clean with alcohol or other cleaner removing any oil or grease.
2. Locate the place where you want to install the Armor. Please note if any trimming is required for clicker buttons or harness lugs.
3. Remove the backing of the Armor and carefully place the Armor onto the reel.
4. Smooth the Armor from the inside out to remove any bubbles.
5. Go catch that "fish of a lifetime"!

Visit our website for step by step visual instructions.

P.O. Box 1988, Glendora California 91740
office (626) 963-1142 fax (626) 963-8672
tim@swiftymfg.com www.swiftymfg.com

Swiftly Manufacturing is dedicated to helping anglers nurture the environment by providing high quality, environmentally safe fishing products.