



Spectra Adhesive Instructions

1. Prepare the connection by inserting your monofilament or fluorocarbon leader or topshot into your dry hollow spectra using your favorite technique. Make sure that the spectra is pulled down tight on the leader material prior to applying the adhesive.
2. If you are installing a crimp, do so following the instructions in manufacturer's kit.
3. If you are serving this connection, do so at this point.
4. Locate the point where the leader material exits the hollow spectra. This is the area where you will be applying the adhesive. Holding the line horizontal, apply one or two drops of adhesive. Flick the line with your finger to ensure complete penetration of the adhesive. Now place one or two drops of the activator on the adhesive to complete the curing process. The activator will ensure that the bonding process is complete. (DO NOT SQUEEZE THE BOTTLES)
5. Test the connection by slowly pulling on the spectra and the leader material.
6. Go catch that "fish of a lifetime"!

Caution: This adhesive will bond to skin. It can be removed easily using peanut oil. Observe all cautions for these products. To extend shelf life, store the adhesive in the refrigerator.

P.O. Box 1988, Glendora California 91740
office (626) 963-1142 fax (626) 963-8672
tim@swiftymfg.com www.swiftymfg.com

Swift Manufacturing is dedicated to helping anglers nurture the environment by providing high quality, environmentally safe fishing products.