



Line Remover Instructions

1. Insert the spindle into a drill motor.
2. Attach both halves of the Swiftly with the wing nut & washers. (Only if disassembled)
3. Place the drill motor into a secure device.
4. Place fishing reel in free spool (conventional) or open bail (spinning reel).
5. Do not run line through rod guides.
6. Wrap line around the Swiftly. (DO NOT TIE)
7. Place drill motor in the "forward" rotation.
8. **Extreme care** must be taken not to allow your fingers to be exposed to the spinning spools.
9. Firmly hold the fishing reel while depressing drill motor trigger.
10. Remove the used fishing line from the fishing reel.
11. Just before the fishing reel is empty, stop the drill motor.
12. Cut the remaining line off the fishing reel.
13. You can continue emptying additional reels until it is full. Once full, split the 2 halves by removing the wing nut.
14. Please recycle the used fishing line by returning it to your local tackle store.

P.O. Box 1988, Glendora California 91740
office (626) 963-1142 fax (626) 963-8672
tim@swiftymfg.com www.swiftymfg.com

Swiftly Manufacturing is dedicated to helping anglers nurture the environment by providing high quality, environmentally safe fishing products.