

Spectra Cleaner Instructions

1. Remove your soiled spectra using the Swifty PowerWasher system.
2. Mix 3 capfuls of Cleaner Solution to one gallon of cold water in a bucket. The container will make 3 gallons of solution.
3. Once the line is secured to the insert, place the insert into the bucket. Agitate the inserts in the bucket of solution for 15 seconds every 15 minutes. After one hour, the line is clean. Rinse in cold water.
4. Dry your line completely prior to returning to you clean spool. Make sure you place the proper amount of tension on the spectra during the re-loading process.

Visit our website for step by step visual instructions.

This product is an organic, biodegradable product safe for the environment.

P.O. Box 1988, Glendora California 91740
office (626) 963-1142 fax (626) 963-8672
tim@swiftymfg.com www.swiftymfg.com

Swifty Manufacturing is dedicated to helping anglers nurture the environment by providing high quality, environmentally safe fishing products.